


EXTERNAL ADJUSTABLE SCREWDRIVER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	79-842301	Motor Housing	28	80228	Clamp Nut
2	50102	Spring Pin (3x22)	29	80229	Drive Dog
3	82-842103	Air Inlet	30	80230	Retaining Ring (3)
4	84204	Throttle Lever	31	80231	Retaining Ring (3) (RTW-21)
5	60-601105	Pin	32	80232	Cam Spindle
6	82-842206	Reverse Valve	33	40145	Steel Ball (1/8")
8	5J-842308	Spring	34	80234	Clutch Carrier
9	75-725145	Rubber Spacer	35	80235	Steel Ball (4) (1/4")
10	75-725146	Valve Stem	36	80236	Washer
11	80214	End Plate	37	802F37	Spring
12	030113	Ball Bearing (626zz)	38	80238	Washer
13	052213	Ball Bearing (696zz)	39	802F39	Adjust Nut
14	82-842214	Rear End Plate	40	80240	Spacer
15	80215-12	Rotor	41	82-8422F41	Clutch Housing
16	80216	Rotor Blade (5)	42	80242	Ball Retainer
17	80217-13	Pin (2.5x55)	43	80243	Spring
18	80218-22	Cylinder	44	80244	Washer
19	75-725119	Front End Plate	45	70117	Spring Pin (2x5)
20	80220	Spring	47	795847	O-Ring (2) (15.8x2.4)
21	80221	Spring Guide	48	5J-842321	Reversing Valve Knob
22	80222	Internal Gear	49	OR03100105	O-Ring (31x1.5)
*23	80223-11	Planet Gear (3)	50	82-842250	Muffler Material
	80223-14	Planet Gear (3)	51	5J-842353	Rear Cover
24	30124	Pin (4) (4x13.8)	52	82-842252	Rubber Grip
*25	80225	Bushing (3) (4x7x8)	56	82-842257	Hook
	080245	Needle Bearing (3)	57	600324	Key
26	80226	Work Spindle	58	10022	Hex. Wrench (1/4")
27	080227	Ball Bearing (6201z)			

*Optional Parts

82-8423F-0001